






Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb /
 Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļi

XX = AA, AD ...

Pos.	Part No.
1	F 960 199 XX
2	F 960 005 XX
3	F 960 432 XX
4	A 960 569 NU
5	F 960 104 XX
6	F 960 014 NU
8	F 960 023 NU
8a	F 960 183 NU
9	F 960 223 XX
10	F 960 222 XX
11	F 960 230 XX
11	F 960 231 XX
12	F 960 185 NU
13	F 960 175 XX
14	F 960 217 NU
15	F 960 103 XX
16	A 963 305 NU
17	F 960 211 AA
	F 960 211 NU
18	H 960 103 XX
19	H 3699 XX




F1119



F1118

0119 / A 866 477
 (+ A 865 665)
 Made in Germany




A5 GEOMETRY
 F 1118 .. F 1119 ..




BORMA



Ideal Standard International NV
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





	P	bar				Q (3 bar)
	T	°C				l/min
						9

